

i³ Digital I/O Tutorial

Introduction

The purpose of this tutorial is to demonstrate how to configure the on-board digital I/O of the i³.

The i³ accepts inputs from devices that provide either a PNP or NPN signal. This needs to be configured in hardware and the user program.

Hardware Setting

JP1 Setting for the Digital I/O

The digital inputs and outputs can be set to 0V common (NPN) or 24V pull up (PNP). To access the Jumpers that configure the physical I/O, disconnect the i³ and remove the back cover (shown in Figure 1.)




Figure 1: Removing the Back Cover





Figure 2: Position of the JP1

Description	JP1 Position
24V Pullup (PNP)	2-3
0V Common (NPN)	1-2

When the i³ is in 24V pull up mode a 24V signal is required to drive an input ON.

When in 0V common mode the input will be activated when the connection between 0V and the input has been closed. These also depend on whether the software has been set to active high or active low.

Setting the inputs in the i³ configuration software



i³ Digital I/O Tutorial

Module Configuration

I/O Map | Module Setup

Module:
Model: 20B05
Description: 24DC in, 16DC out, 2 10-bit AI, 4 HSC, 2 PWM

Type	Starting Register	Ending Register	Number of Registers
%I	1	32	32
%Q	1	24	24
%AI	1	12	12
%AQ	1	8	8

OK Cancel Apply

Click on the module set up

i³ description of I/O

Module Configuration

I/O Map | Module Setup

Digital In / HSC Digital Out / PWM

Analog In Analog Out

OK Cancel Apply

Click on the Digital In / HSC to set whether the inputs will be Active High or Active Low

Digital / HSC Input Configuration

Digital inputs active mode

☒ Positive Logic ☐ Negative Logic

Note: This setting must match that of the jumpers on the product

High Speed Counters

Type:	Mode:	Counts per Rev: (0 = full 2 ³² counts)
#1 Disabled	%I9	0
#2 Disabled	%I10	0
#3 Disabled	%I11	0
#4 Disabled	%I12	0

OK Cancel

Set here whether to have active high inputs or active low. Click OK and download to the i³ with the program

i³ Digital I/O Tutorial

Digital Inputs in the Program

If the input coils are shown as active, when the input is not activated (whether it be 0V common or 24V pull up) then it is likely that the i³ is set as Active LOW.

Input 1 and 2 are not activated, however the contact is closed.



Input 1 is now activated and the contact has gone open.



The unit has now been set to Active HIGH. When there is not a signal to the input the input is not activated. However, when a signal is applied the input is activated.

Input 1 and 2 do not have a signal going to them and the contacts are open.



Input 1 now has a signal applied and input 1 contact is closed.



Active High and Active Low operate directly opposite to each other.

www.imopc.com

IMO Precision Controls Ltd

Unit 3, The Interchange, Frobisher Way
Hatfield, Hertfordshire AL10 9TG UK

Tel: +44 (0)1707 414 444
Fax: +44 (0)1707 414 445

Email: sales@imopc.com
Web: www.imopc.com



Bespoke technical training courses
available at our Hatfield training facility.
Call 01707 414 444 for more information